

**! CAUTION**

- All wiring should be done by a licensed electrician in accordance with state codes, local codes and National Electric Code (NEC) standards.
- Improper installation may result in serious injury and void warranty.
- Contains parts and assemblies susceptible to damage by electrostatic discharge (ESD).

Included in the EcoMod<sup>®</sup> 2 Series Extension Kit: two (2) extension brackets (Item 1), four (4) aiming washers (Item 2), eight (8) flat head screws (Item 3), two (2) M12 bolts (Item 4), two (2) M12 nuts (Item 5), two (2) M12 lock washers (Item 6) and four (4) M12 flat washers (Item 7).

**Installation**

1. Disconnect power.
2. Assemble extension brackets (Item 1) per drawing.
3. Remove fixture from mounting harp.
4. Remove aiming washers (Item 2) from harp.
5. Reinstall aiming washers (Item 2) on outside of harp as shown in drawing.
6. Mount extension bracket (Item 1) on fixture and harp as shown in drawing with M12 bolts (Item 4), M12 nuts (Item 5), M12 lock washers (Item 6) and M12 flat washers (Item 7).
7. Reconnect power.

