


! CAUTION

- All wiring should be done by a licensed electrician in accordance with state codes, local codes and National Electric Code (NEC) or International Electrotechnical Commission (IEC) standards.
- Improper installation may result in serious injury and void warranty.
- Contains parts and assemblies susceptible to damage by electrostatic discharge (ESD).
- Make sure the fixture is disconnected from any power source before removing from the wall.

Mounting

1. Remove fixture from wall.
2. Remove screw (Item 1) and rotate driver plate (Item 2) up as shown below in Figure 1.
3. Remove switch (Item 3) by pressing down on the locking tabs and pulling out in the direction shown below in Figure 1.
4. Disconnect all driver wiring connections, including all cage clamp connections (two total) and flag terminals on switch (three total).
5. Unscrew ground terminal nut on driver plate. Keep all hardware for re-installation.
6. Install new driver assembly. Start by re-connecting the ground terminal wire to the new driver plate.
7. Route the flag terminal connections through the hole for the switch. Re-connect all wires according to the diagram in Figure 2.
8. Re-connect LED output wires using the original cage clamp connectors. Red is positive (+) and Black is negative (-).
9. Re-install the plate while ensuring all wire connections are secured inside the compartment. Re-install screw (Item 1) from Figure 1.
10. Re-mount fixture to wall.

Figure 1



FlexPro docklite® Driver Kit

Installation Instructions

PHOENIX®
DURABILITY X DESIGN™

Figure 2





Figure 3



Product design and specifications are subject to change without notice.



Phoenix Lighting 8711 West Port Avenue Milwaukee, WI 53224 USA
Phone: +1 414.973.3300 Toll Free: 800.438.1214 Fax: +1 414.973.3210 www.phoenixlighting.com

N5499874A
11.16.21