Installation & Aiming

1. Install fixture according to Installation Instructions provided with the fixture. Position the fixture with the arm in a straight line.

2. Place one hand on the light head and the other hand on the flexible arm (see above for hand placement in relation to reinforced area).

3. Position the fixture using one long continuous curve. Do not position fixture along re-inforced arm as this will not hold a curve.

reinforced area

Helpful Tips

Springs will stiffen with increased movement and colder weather.

Do not overbend the fixture.

Do not aim using sharp angles at either endpoint.

Aim the fixture and use the mounting bracket to swing the fixture in and out of the way as necessary.

Product design and specifications are subject to change without notice.

Phoenix Products Company Inc. 8711 West Port Avenue Milwaukee, WI 53224 USA
Phone: +1 414.973.3300 Toll Free: 800.438.1214 Fax: +1 414.973.3210 **www.phoenixlighting.com**