


! CAUTION

- All wiring should be done by a licensed electrician in accordance with state codes, local codes, and National Electric Code (NEC) standards or International Electric Commission (IEC) standards.
- Improper installation may result in serious injury and void warranty.
- When using luminaires, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury.

Included in the Conveyo™ Photocell Receptacle Kit: photocell receptacle, driver cover, gasket and four (4) M5 screws.

Installation

1. Disconnect power from fixture
2. Remove four (4) M5 screws from driver cover.
3. Locate the black (line) and white (neutral) wires within the fixture and remove crimp.
4. Connect the white wire from the photocell receptacle kit and the white wire from the driver to the white incoming power wire using a 3 position connector.
5. Connect the black wire from the photocell receptacle kit to the black incoming power wire.
6. Connect the red wire from the photocell receptacle kit to the black wire from the driver.
7. Ensure no wire connections are pinched when reattaching driver cover to fixture. Secure driver cover to fixture using four (4) M5 screws (supplied).
8. Loosen two (2) Philips head screws on photocell receptacle.
9. Using a flat head screwdriver, route “inner portion” of photocell receptacle so the arrow points North.
10. Retighten the two (2) Philips head screws on receptacle to compress gasket, but do not over-tighten.



Product design and specifications are subject to change without notice.

